

Easy to use!

High Performance!

Great low price!

ATAGO®

Ethylene Glycol Checker!!

Digital Hand-held "Pocket" Ethylene Glycol refractometer

PAL-91S, PAL-92S

Cat.No.4491,4492

Application

The "Pocket" Ethylene Glycol refractometer, PAL-91S and PAL-92S, easily measure the coolant in brine and other agents of Ethylene Glycol. Measured value displayed digitally.

The freezing point of the sample can also be measured and displayed.

Feature

- Calibration with water only
- Measurement in 3 seconds
- Extremely water resistant (IP65)
- Light & Compact, 100g
- Ergonomically designed for easy, one-handed operation
- Convenient storage case
- Automatic Temperature Compensation (ATC)
- Designed with a strap holder option

Measuring Method



① Place the sample onto the prism surface.



② Press the START key.



③ The measurement value will be displayed in 3 seconds.



④ ***Secondary Scale:** Press the START key for 2 seconds while the concentration (%) is indicated, to display the freezing point (°C/°F).



Actual Size

Specification

	PAL-91S	PAL-92S
Measurement range		
Concentration of Ethylene Glycol *Main scale	0.0~90.0% (V/V)	0.0~90.0% (V/V)
Freezing point of Ethylene Glycol *Secondary scale	0~-50°C	32~-60°F
Resolution		
Concentration of Ethylene Glycol *Main scale	0.2% (V/V)	0.2% (V/V)
Freezing point of Ethylene Glycol *Secondary scale	1°C	1°F
Measurement accuracy		
Concentration of Ethylene Glycol *Main scale	±0.4% (V/V)	±0.4% (V/V)
Freezing point of Ethylene Glycol *Secondary scale	±1°C	±1°F
Measurement temperature	10~40°C (Automatic Temperature Compensation)	50~104°F
Sample volume	0.3ml or more	
Measuring time	3 seconds	
International Protection Class	IP65 Water Resistant	
Power supply	2 × AAA Batteries	
Battery life	Approx 11,000 measurements (When an alkaline battery is used)	
Dimensions and weight	55(W) × 31(D) × 109(H)mm, 100g (Main Unit only)	

All ATAGO refractometers are designed and manufactured in Japan.



HACCP G.M.P. G.L.P.

ATAGO products are acknowledged by HACCP, G.M.P. and G.L.P.

ATAGO CO.,LTD.

Headquarters: 32-10, Honcho, Itabashi-ku, Tokyo 173-0001 Japan
TEL: 81-3-3964-6156 FAX: 81-3-3964-6137
overseas@atago.net http://www.atago.net/

ATAGO U.S.A., Inc.

12011 NE First Street, Bldg. C, Suite 110 Bellevue, WA 98005 U.S.A.
TEL: 1-425-637-2107 FAX: 1-425-637-2110
customerservice@atago-usa.com http://www.atago.net/

ATAGO INDIA Instruments Pvt. Ltd.

A-501, Mangal Aarambh Business Centre, Near Kora Kendra, Off. S.V. Road, Borivali (West), Mumbai-400 092 India
TEL: 91-22-2833-8038 / 8076 FAX: 91-22-2899-8164
customerservice@atago-india.com



*Specifications and appearance are subject to change without notice.